

Before commencing assembly, please read these instructions thoroughly.

EXTRA-260



SPECIFICATIONS

Wing Span: 928mm (36.5")
Length: 890mm (35")
Weight: 650g (22.9oz)
Wing Area: 20dm² (310sq in)
Wing Loading: 32.5g/dm² (11.5 oz/sq in)
Engine: brushless motor (380-200w)

INSTRUCTION MANUAL

INDEX

REQUIRED OPERATION	-----	2
BEFORE YOU BEGIN	-----	2
ASSEMBLY	-----	3




SAFETY PRECAUTIONS


- First-time builders should seek the advice of experienced modelers before commencing assembling and if they do not fully understand any part of the construction.
- You are responsible for this model's assembly and safe operation!
- Always keep this instruction manual ready at hand for quick reference, even after completing the assembly.

REQUIRED FOR OPERATION (Purchase separately!)

1 4 Channel R/C Transmitter




3 Brushless Motor




5 Propeller




2 4 Channel Mini R/C receiver




4 Reduction gear case



6 Instant Glue



7 Power battery





8 Speed Controller





TOOLS REQUIRED (Purchase separately!)

Sharp Hobby Knife 

Needle Nose Pliers 

Screw Driver 

Scissors 

Wire Cutters 

Awl 

BEFORE YOU BEGIN

1 Read through the manual before you begin, so you will have an overall idea of what to do.

2 Check all parts. If you find any defective or missing parts, contact your local dealer.

3 Symbols used throughout this instruction manual, comprise:



Apply C.A Glue



Apply A.B Glue



Apply P.A Glue



Assemble left and right sides the same way



Drill holes with the specified diameter (here: 2mm)



Purchase separately



Pay close attention here



Ensure smooth non-binding movement while assembling



Cut off shaded portion

1

Main Wing



Wing Top



C.A.




Be sure to apply instant type CA glue to both sides of each hinges. (Low viscosity type)

2

Main Wing



Wing Bottom





Linkage Stopper 2

Horn 2


1 X 130mm Rod 2

3 Front Landing Gear




	2 X 8mm TP Screw	2
	2 x 25mm Screw	2
	2mm Nut	6
	3 x 10mm Screw	2


4 Horizontal/Vertical Tail





	2 X 8mm TP Screw	2
	Stator	1





Be sure to apply instant type CA glue to both sides of each hinges. (Low viscosity type)



5 Rudder Servo



6 Elevator Servo



Horn 2




Linkage taper 2






1 x 130mm Rod 2

7 Brushless Motor

The Way Of Install
The First




The Way Of Install The Secondly



8

Cowling

2 X 8mm TP Screw



2 X 8mm TP Screw


4



9

Main Wing






Aluminum Joint Stick

-  1
-  M3 x 15mm Screw 2
-  3MM Washer 2


10 Controls



Motor controller



Batteries




Receiver

11 Canopy




A
B




T2 X 8mm TP Screw 4

Center of Gravity



Wing Symmetry



$$A = A'$$